


REMOTE FUNCTIONS

HOW TO USE YOUR REMOTE CONTROL



To Purchase a Movie on Pay-Per-View:

[You must buy the movie before or within 10 minutes of the start time]

1. Enter channel **701 - 707**
2. Press **Guide**
3. Use **Arrow** keys to view movies/events for the day
4. Highlight the movie/event you would like to buy and press **OK**
5. Scroll to **Buy PPV** and press **OK**
6. The purchase price will be displayed. Select **Buy** to purchase the movie/event.
7. Your movie/event will then begin on schedule.

My Library Menu:

1. Press **Menu** button
2. Scroll to highlight **My Library**
3. Press **OK**
4. Information is located here for Videos, PPV Events, Pay Per Blocks, Sports Packages, Reminders, Messages, and Caller ID.
5. Scroll to category; highlight and press **OK** to view the stored information.

SETTINGS - Access requires a password. Bloomer Telephone Company will assign a default password that you may change as you wish.

HARDWARE SETTINGS - These settings will be handled by your Bloomer Telephone Company technician upon installation. They will be selected based on your TV.

PROGRAMMING YOUR REMOTE CONTROL - Visit our website for complete instructions on how to program your remote to control your TV.

www.bloomer.net/digital-tv/helpful-hints



1120 15th Ave., Bloomer, WI 54724
715.568.4830

www.bloomer.net

Turn On Your TV Using the Remote Control:

Press the center button labeled **Power**.

Finding a Channel/Program or Changing Channels:

1. Enter the desired channel number.

OR

2. Press **Guide** to view complete list of channels. Scroll through the channel line up using the **up/down arrow keys** or the **CH** button (scrolls by page). Select desired channel by pressing **OK** twice. Using the **Day -** and **Day +** buttons will forward the programming guide 12 hours in advance. The buttons are located on either side of the **Page +/-** button which scrolls by page.

Menu Button:

Guide – Takes you to the channel lists.

DVR – **Available with DVR Service**, this will take you to a list of your recordings and scheduled events.

My Library – Stores information such as your Caller ID, PPV Events, and Recordings.

Settings – Requires a password.

Parental Controls – If applicable to your service – Please call our office if you are interested in setting up Parental Controls.

Favorites – Set up your “Personalized Guide” – Please call our office if you are interested in setting up a “Personalized Guide”.

Search – Search the Guide.

Programming Guide:

Your Programming Guide has multiple **tabbed** channel lists [based on your package]. Examples: All, HD, Subscribed, PPV, Favorites. Press **Guide** repeatedly to scroll through the Guide tabs.

“Gold Star” – On Your Channel Guide: A “Gold Star” ahead of the name of the program listed on your channel guide means that the program is not a re-run.

Closed Caption:

Displays text/transcript of the program you are watching. Press **CC** button on your remote to enable closed captions, press **CC** again to disable it.

Channel Action:

Press **Guide**

1. Highlight the Program you wish to take an action with: Press **OK**.
2. A Secondary Menu will read:
 - Schedule Event** – Schedules Reminders and Autotunes. Also edits recorded show time-frames and frequencies on your *DVR*.
 - Record Program** – Record a program to your *DVR*.
 - Record Series** – Record a program series to your *DVR*.
 - Set Reminder** – Set a reminder of an upcoming show.
 - Set Autotune** – Choose to have your TV automatically tune to a show.
 - Add to Favorites** – Select and choose to add to your favorites list, if you have set up a “Personalized Guide”.
 - Expanded Info** – Displays more detail about the program.
 - Cancel** – Cancels last action.

Schedule Event (DVR):

1. Press **Guide** button.
2. Use arrow keys to scroll through channels to find program of choice and press **OK**.
3. Select **Schedule Event** and follow the instructions on the screen.

Record Programs (DVR):

1. Press **Guide** button.
2. Use arrow keys to scroll through channels to find the program of choice and press **OK**.
3. Highlight **Record Program** and press **OK**.
4. A **red dot** will appear next to the name of the program that is being recorded.
5. You may select **OK** again to edit your recording.

Record Series (DVR):

1. Press **Guide** button.
2. Use arrow keys to scroll through channels to find the program of choice and press **OK**.
3. Highlight **Record Series** and press **OK**.
4. **Two red dots** will appear next to the name of the program series that is being recorded.
5. You may select **OK** again to edit your recording.

DVR Function Buttons:

Available with DVR Service

The **Pause/Resume** live TV button is located under the **Green DVR List** button on the remote control. Other function buttons located in this area are **Rewind**, **Fast Forward**, **Stop**, and **Record**. Use these function buttons to control the LIVE program you are currently watching.

To View A Recorded Program:

1. Press **Menu** button.
2. Scroll down to **DVR** and press **OK**.
3. Highlight **Recordings** and press **OK**.
4. Highlight the program of choice and press **OK**.
5. The following options will appear:
 - a) Play Recording
 - b) Resume Play
 - c) Lock (Blocks other users from deleting your recordings)
 - d) Delete Recording
 - e) CancelHighlight your selection and press **OK**.

Setting a Reminder:

1. Press **Guide** button.
2. Use arrow keys to scroll through channels to find program of choice and press **OK**.
3. Use arrow keys to scroll down to **Set Reminder** and press **OK**.
4. When a reminder is set, a picture of a **clock** will appear on the channel that was chosen.
5. You may select **OK** again to edit your reminder.

Setting Autotune:

1. Press **Guide** button.
2. Use arrow keys to scroll through channels to find the program of choice and press **OK**.
3. Highlight **Set Autotune** and press **OK**.
4. An **orange ball** will appear next to the name of the program that is being set for autotune. The channel will automatically change when the program begins.
5. You may select **OK** again to edit your autotune.